## Addendum

## K641+ Keypad

Use the following instructions to remove the K641+ Keypad cover.

## To Remove the K641+ Cover:

 Insert a flathead screwdriver at about 30° into the tab located at the bottom of the K641+ housing. Gently push the screwdriver downwards as shown.



2. Repeat for the second tab to release the K641+ cover.



3. To close the cover, align top plastic tabs and snap housing into place.

K641+-EQ00 Printed in Canada - 02/2014